




CONTENTS

English	1-7
日本語	8-14

The diagram illustrates the contents of the product box. On the left is a long, thin, black computer soundbar with a silver grille and a small 'SK100Li' label. On the right is a white rectangular box labeled 'NYLAVEE' with 'NYLAVEE SK100Li' printed below it. Below the soundbar is the text '1 x Computer Soundbar (SK100Li)', and below the manual box is the text '1 x User Manual'.

Product Diagram

The diagram shows the LTV-1000 LED light bar with its components and connections labeled as follows:

- 1 Volume Knob
- 2 Power Indicator
- 3 LED light strip
- 4 USB power plug
- 5 3.5mm audio plug


The light bar is shown with a USB cable connected to the back, which has a USB-A plug (4) and a 3.5mm audio plug (5). The light bar has a volume knob (1) and a power indicator (2) on the right side. The LED light strip (3) is located on the front of the bar.

Button Control			
Function	Operation	Cue Tone	LED Indicator
Power On	Plug the USB cable into USB charging adapter or activate the computer USB port	Beep	Light on
Power Off	Unplug the USB cable	NA	Light off
Mode Switch	Press the volume knob and hold for 3s	Bluetooth mode / Wired mode	Light flashing red and blue When in Bluetooth mode and pairing
Disconnect Bluetooth	Press the volume knob and hold for 5s in Bluetooth mode	Disconnected	
Clean Pairing Record	Press the volume knob and hold for 10s in Bluetooth mode	Bluetooth mode	
Play / Pause	Click the volume knob	NA	NA
Volume +/-	Turn the volume knob clockwise or counter clockwise	Beep when highest volume is reached	NA
Light Mode Switch	Double click the knob	NA	Light switching in the order: Symphony / Rhythm / Gradient / Breathing / Off

Wired Connection

No built-in batteries, the soundbar is powered by the USB cable connected to either the desktop, laptop, USB charger, etc.

Wired Connection via 3.5mm Plug



The diagram illustrates a wired connection between a laptop and a soundbar. A 3.5mm audio cable is plugged into the laptop's audio port. The soundbar is shown with a dashed line pointing to its back, labeled 'Back'. The soundbar has a volume knob and a power button on its side.

- 1 Press and hold the volume knob for 3s to switch to Wired mode, the voice prompt "Wired Mode" will be heard. (Default Wired mode when booting for the first time)
- 2 Plug the 3.5mm Audio Cable into the 3.5mm port of your device.

Wireless Connection via Bluetooth

- 1. Switch to Bluetooth mode**
 - 1 Press and hold the volume knob for 3s to switch to Bluetooth mode, the voice prompt "Bluetooth Mode" will be heard.
 - 2 The LED light will flash red and blue alternately when entering Bluetooth pairing
- 2. Pair with your device**
 - 1 Turn on the Bluetooth of your device and search for nearby devices.
 - 2 Find "SK100LI" in the search results and tap to connect.
 - 3 Once connected, the voice prompt "Connected" will be heard, and the light will return to the mode before pairing.

Note:

- Make sure the sound bar is not connected to other non-targeted device.
- When the speaker is connected to a non-target device and you do not know which device is connected, long press the knob for 5s to force disconnect the non-targeted device.
- Keep the soundbar and your device within 16ft/5m.

5

Attention

Troubleshooting of Sound Issues

If no sound comes out from the soundbar, please try the following:

- Rotate the volume knob clockwise to raise the volume of the soundbar.
- Adjust the volume on your device.
- Press the volume knob to resume in case the soundbar paused.
- Unplug and re-insert the adapter.

Troubleshooting the Bluetooth Connection

- Make sure that the soundbar Bluetooth pairing mode is on(Light flashing red and blue).
- Make sure the Bluetooth of the soundbar is not connected via Bluetooth to any other device.
- Unplug the 3.5mm Audio Cable from your device.
- Delete "SK100LI" pairing record on your device, then search for "SK100LI" and connect again.

6

Worry-free Service Guarantee

- 30 days free return and replacement.
- 18 months warranty.
- Lifetime friendly customer service.

Please contact us for more details and further instructions at
support@nylavee.net

2-year extended warranty:
www.warranty-hub.com

Tips: The warranty code is on the USB cable

FCC Compliance
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must withstand any interference received, including interference that may cause undesired operation.

FC CE RoHS

1*PCサウンドバー(SK100Li)


1*取扱説明書

商品仕様

型番	SK100Li
接続	Bluetooth 5.0 & 3.5mm AUXポート
電源	USB/バスパワー
入力	DC5V/2A Max

8

製品詳細



① 音量ノブ
② 電源表示ランプ
③ LEDライト
④ USBケーブル
⑤ 3.5mmケーブル

9

ボタンコントロール			
機能・状態	スピーカー側操作	音声プロンプト	LED 表示
電源オン	USBを電圧アダプターまたはパソコンのUSBポートに接続する	ビープ音	LEDライトが点灯
電源オフ	USBケーブルを取りはずす	/	LEDライトが消灯
モード変更(BT/AUX)	音量ノブを3秒間長押し	Bluetooth mode/ wired mode	Bluetoothモードとペアリングが完了LEDライトが青と赤に交互に点滅
Bluetooth接続を解除	Bluetoothモード中、音量ノブを5秒間長押し	Disconnected	
ペアリング情報を削除	Bluetoothモード中、音量ノブを10秒間長押し	Bluetooth mode	
再生/一時停止	音量ノブを押す	/	/
音量 +/-	音量ノブを時計回り/反時計回りに回す	音量が最大レベルに達すると、ビープ音	/
LEDライトモード変更	接続中音量ノブをすばやく2回押す	/	ライトの切り替え順序シフト オニールスム/グラデーション オフ

有線接続

内蔵バッテリーではなく、スピーカーはUSBケーブルで電力を供給し、デスクトップ、ノートパソコン、USB充電器などに接続できます。

USB & AUX 3.5mmケーブルの接続

The diagram illustrates the connection of the USB & AUX 3.5mm cable. On the left, a laptop is shown with a callout indicating the connection point. A cable with a USB-A connector on one end and a 3.5mm audio jack on the other is shown. The USB-A connector is plugged into the laptop's USB port. The 3.5mm audio jack is plugged into the back of a speaker, which is shown on the right. A dashed line points to the back of the speaker, labeled '背面' (Back).


- 1 本製品への付属のUSBケーブルを、市販のUSBポート付きアダプターまたはPCのUSBポートに接続し、本体の電源を入れます。
- 2 「Wired mode」という音声プロンプトが聞こえるまで、音量ノブを3秒間長押しします。
(初めて使用する場合スにスピーカーが有線接続モードです。)
- 3 3.5mmオーディオケーブルを外部接続機器の3.5mmポートに接続します。

Bluetooth接続

1. Bluetoothモードに切り替える

- ①「Bluetooth mode」という音声プロンプトが聞こえるまで、音量ノブを3秒押し続けて、Bluetoothモードになります。
- ② LEDライトが青と赤で交互に点滅してペアリングモードになります。

2. ペアリングをする



- ① 接続したい機器のBluetoothをONにして、本製品を検索します。
- ② 相手側機器の画面に「[S-K100L]」を選択します。
- ③ ペアリングに成功する【connected】音声プロンプトとともに、LEDライトはペアリングする前のモードに戻ります。

ペアリングに成功するとビープ音とともに、Bluetoothランプが5秒ごとに青く点滅します。

注意

1. スピーカーが対象外のデバイスに接続されていないことを確認してください。

2. スピーカーが未知のデバイスに接続された場合、音量ノブを5秒間押しすると、接続を強制的に切断することができます。

3. 本製品とBluetooth対応機器の距離5m以内にな近づけてください。

12

取り扱い上の注意

音が出ない

- ▶ 音量ノブを回して音量を調節してください。
- ▶ 接続機器の音量を大きくしてください。
- ▶ 音量ノブを押して、スピーカーが一時的に停止した場合に再生します。
- ▶ USBケーブルと3.5mmオーディオケーブルを再接続してください。

Bluetooth接続できない

- ▶ スピーカーのBluetoothペアリングモードになっていることを確認します。(LEDライトが青と赤に交互に点滅)。
- ▶ スピーカーが対象外のデバイスに接続されていないことを確認してください。
- ▶ デバイスの3.5 mmオーディオケーブルを取り外します。
- ▶ 対応機器に本製品とのペアリング情報【SK100L】を削除してから、再度ペアリングの操作を行ってください。

アフターサービス

- 30日間返品・交換無料
- 18ヶ月保証
- 生涯サポートサービス

アフターセールスについての詳細は、
support_jp@nylavee.net お問い合わせください。

2年間の保証期間延長
www.warranty-hub.com

注意：保証コードはUSBケーブルに結びつけられています。







219-239228