NYLAVEE

USER MANUAL


Computer Speaker | SK600






Function	Operation	Voice Prompt	LED Indicator
Plug in	Insert the USB plug into any USB charging adapter or active computer USB port	1	Green light on for 1 second
Power on	Hold the Power Button for 2 seconds	Веер	LED flashing red and blue alternately (It defaults to Bluetooth mode when it's turned on for the first time)
Power off	Hold the Power Button for 5 seconds	Веер	Red light on for 1 second
Play/Pause	Press the Power Button once	/	1
Switch to Bluetooth/ Aux-in mode	Press the Mode Button once	Веер	1
Bluetooth pairing	1	Веер	LED flashing red and blue alternately
Bluetooth connected	1	Веер	1
Disconnect Bluetooth	Hold the Mode Button for 5 seconds	Веер	LED flashing red and blue alternately
Toggle music effect	Press the EQ Button once	Bass, Balance	1
Volume +	Turn the Volume Knob clockwise	1	1
Volume -	Turn the Volume Knob counter clockwise	1	1
Change lighting modes	Tap the LED Touch Point once	1	① rhythm ② flow ③ breathing
Turn off/on the Light	Hold the LED Touch Point for 2 seconds	/	Light off/on
Reset	Hold the EQ Button for 10 seconds	/	1

Worry-free Service Guarantee





Troubleshooting of Sound If there is no sound comes out from the speaker, please try the following operations: ➤ Rotate the volume knob clockwise to raise the volume of the speaker. Adjust the volume on your audio source device. ➤ Press the volume knob to resume in case the speaker paused. ➤ Re-insert the USB plug and restart. **Troubleshooting of Bluetooth Connection** ➤ Make sure the Bluetooth of the speaker is not connected by other devices. ➤ Unplug the 3.5mm Audio Cable from your device. ➤ Delete "SK600" memorized on your device, then search for "SK600" and connect again.

• 18 months warranty. • Lifetime friendly customer service. Please contact us for more details and further instructions via support@nylavee.net Extend 2-years warranty: www.nylavee.net

• 30 days free return and exchange.