


# NYLAVEE

## USER MANUAL

Computer Speaker | **SK600**

### Package Included




### Specification

Model	SK600
Two Connection Options	Bluetooth & 3.5mm Aux-in
Power Supply	Adapter powered
Power Input	DC 9V $\equiv$ 1.5A Max
4 RGB Lighting Modes	① Symphony ② Rhythm ③ Flow ④ Breathing

1

### Product Diagram



2

### Button Control

Function	Button	Operation	Light indication
Wake up		Press the Power Button and hold for 3s	Green light flow
Sleep		Press the Power Button and hold for 3s	Red light flow
Play/Pause		Press the Power Button	NA
Switch between Bluetooth / Aux mode		Press the Mode Button	The LED light flashes red and blue when switching to Bluetooth mode for pairing (Default bluetooth mode when booting for the first time)
Disconnect Bluetooth		Press and hold for 5s	Light flashing red and blue alternately
Toggle music effect		Press the EQ button	NA
Volume +/-		Turn the Volume Knob clockwise / counter clockwise	NA
Switch light mode		Tap the LED Touch button	①symphony ②rhythm ③ flow ④ breathing
Light on / off		Press the LED Touch button hold for 2s	Light on / off
Reset		Press the EQ button anf hold for 10s	Light flashing red and blue alternately (Restore default settings)

3

### Use Your Computer Speaker

The computer speaker does not have a built-in battery, please power it by the adapter provided in the package.


#### Wireless connection via Bluetooth

##### 1. Switch to Bluetooth mode



- ① The speaker defaults to Bluetooth mode when it is turned on for the first time.
- ② To switch to Bluetooth mode from wired mode, press the Mode Button once.
- ③ When LED flashes blue/red, the Bluetooth mode is on.


##### 2. Pair with your device



- ① Turn on the Bluetooth of your audio source device and search for nearby devices.
- ② Find "SK600" in the search results and tap to connect.

4

#### Wired Connection via 3.5mm Plug



- ① Press the Mode button to switch to the wired mode from Bluetooth mode.
- ② Plug the 3.5mm Audio Cable into the AUX IN port of the right speaker.
- ③ Connect the speaker to your audio source device via the 3.5mm Audio Cable.

5

### Attention

#### Troubleshooting of Sound

If there is no sound comes out from the speaker, please try the following operations:

- Rotate the volume knob clockwise to raise the volume of the speaker.
- Adjust the volume on your audio source device.
- Press the volume knob to resume in case the speaker paused.
- Re-plug the power adapter and restart.

#### Troubleshooting of Bluetooth Connection

- Make sure the Bluetooth of the speaker is not connected by other devices.
- Unplug the 3.5mm Audio Cable from your device.
- Delete "SK600" memorized on your device, then search for "SK600" and connect again.

6

### Worry-free Service Guarantee

- 30 days free return and exchange.
- 18 months warranty.
- Lifetime friendly customer service.

Please contact us for more details and further instructions via

**support@nylavee.net**

Extend 2-years warranty:

**www.warranty-hub.com**

FCC Compliance  
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) this device may not cause harmful interference, and (2) this device must withstand any interference received, including interference that may cause undesired operation.



7